



- | | | |
|---|--|--|
| 1. Left direction indicator. | 17. Zener-diode. | 34. Right handlebar switches. |
| 2. Parking light. | 18. Plug and socket (9-pin). | 35. Cable color code. |
| 3. Dipped headlight beam. | 19. Ignition capacitor. | 36. Black. |
| 4. Main headlight beam. | 20. Ignition coil. | 37. Blue. |
| 5. Main beam warning light. | 21. Contact breaker. | 38. Brown. |
| 6. Oil pressure warning light (250 cm ³ only). | 22. Left handlebar switches. | 39. Red. |
| 7. Right direction indicator. | 23. | 40. Purple. |
| 8. Direction indicator warning light. | 24. Horn. | 41. Green. |
| 9. Headlight switch. | 25. Speedometer light. | 42. Slate. |
| 10. Battery. | 26. Tachometer light. | 43. White. |
| 11. Alternator. | 27. Left direction indicator. | 44. Yellow. |
| 12. Fuse. | 28. Rear light. | 45. Light. |
| 13. Ignition/lighting switch. | 29. Stop light. | 46. Snap connectors. |
| 14. Rectifier. | 30. Right direction indicator. | 47. Ground (earth) connection via cable. |
| 15. Direction indicator unit. | 31. Oil pressure switch (250 cm ³ only) | 48. Ground (earth) connection via fixing bolt. |
| 16. Capacitor (2.M.C.). | 32/ Front and rear brake light switches. | |
| | 33. | |

FIG. G14. *Wiring diagram.*